



**FORCE
WINDER**
PERFORMANCE

www.UseForce.com



INSTALLATION:

ForceWinder for Kawasaki Meanstreak, Nomad and Vulcan 1600.

- 1) Turn off bike and secure for the work to commence.
- 2) Remove the oem air intake system and package in case you need for future.
- 3) Keep the temp sensor
- 4) Continue to plug the "cold start solenoid pipes" and "reed valve hose".
- 5) Bolt adapter onto the throttle body using the oval gasket.
- 6) Insert the 90 degree fitting into the bottom right of the adapter.
- 7) Insert the temp sensor to the bottom left.
- 8) Insert second rectangular gasket then bolt on the ForceWinder elbow.
- 9) Once everything is tightened up slide clamp over elbow and insert filter.
- 10) Tighten filter clamp then add ForceWinder Dry Charger Sock.

TIPS:

- 1) For optimum performance we suggest a tune at a local dyno shop.
- 2) Installation is suggested to be done by a licensed motorcycle mechanic.
- 3) Do not oil the filter - we use a dry filter media that requires zero oil.
- 4) Always ride with the Dry Charger Sock on as it traps debris outside the filter yet provides more than enough air to pass thru for performance.
- 5) It is also easier to remove the sock and wash that then let dry overnight then it is to remove and clean the filter.

ForceWinder has been making air intakes since 1989 - we use quality trades with quality material to make each ForceWinder.

From all of us @ ForceWinder we do appreciate your business. After install please kindly send us some feedback and plenty of pictures. Email or text to:

info@theoriginalforcewinder.com or 928-846-1677