



INSTALLATION:

ForceWinder for SINGLE CARB Honda Shadow Aero, Spirit, Phantom

- 1) Turn off the bike and secure it for the work to commence.
- 2) Remove the oem intake system and store it in case it's needed in the future.
- 3) Slide adapter with ORing Rubber Gasket over the Carb Body
- 4) Snug down the three bolts. Do not over tighten till you align with the elbow so it faces forward.
- 5) Place the gasket over the adapter then bolt on the elbow facing forward.
- 6) Slide hose clamp over the elbow and attach the filter.
- 7) Tighten filter clamp then add ForceWinder Dry Charger Sock.
- 8) Insert the poly fitting onto the vac hose and attach a mini breather.

TIPS:

- 1) For optimum performance we suggest a tune at a local dyno shop.
- 2) Installation is suggested to be done by a licensed motorcycle mechanic.
- 3) Do not oil the filter - we use a dry filter media that requires zero oil.
- 4) Always ride with the Dry Charger Sock on as it traps debris outside the filter yet provides more than enough air to pass thru for performance.
- 5) It is also easier to remove the sock and wash that then let dry overnight then it is to remove and clean the filter.

From all of us @ ForceWinder we do appreciate your business. After install please kindly send us some feedback and plenty of pictures. Email or text to:

info@theoriginalforcewinder.com or 928-846-1677