

www.UseForce.com



INSTALLATION:

ForceWinder for Kawasaki VN 900

- 1) Turn off the bike and secure it for the work to commence.
- 2) Remove the oem intake system and store it in case it's needed in the future.
- 3) Keep the temp sensor
- 4) Attach temp sensor to top of the ForceWinder adapter
- 5) Bolt adapter onto throttle body using the double circle gasket & 4 metric bolts
- 6) Insert the poly 90 degree fitting into the bottom of the adapter
- 7) Plumb the vac hose as needed using the extra ½" hose provided
- 8) Insert rectangular gasket then bolt on the ForceWinder elbow using the 4 ¼ 20's
- 9) Once everything is tightened up slide clamp over elbow and insert filter
- 10) Tighten filter clamp then add ForceWinder Dry Charger Sock
- 11) For the other hose that is the ¾'s attach to oem hose and re route down to the atmosphere for any blow out and attache mini breather at the end of hose

TIPS:

- 1) For optimum performance we suggest a tune at a local dyno shop.
- 2) Installation is suggested to be done by a licensed motorcycle mechanic.
- 3) Do not oil the filter - we use a dry filter media that requires zero oil.
- 4) Always ride with the Dry Charger Sock on as it traps debris outside the filter yet provides more than enough air to pass thru for performance.
- 5) It is also easier to remove the sock and wash that then let dry overnight then it is to remove and clean the filter.

From all of us @ ForceWinder we do appreciate your business. After install please kindly send us some feedback and plenty of pictures. Email or text to:

info@theoriginalforcewinder.com or 928-846-1677